


ECM				
The ECM is located behind the Centre Consol on the Applause.				
On the Feroza it is located behind the Right hand Kick Panel .				
The ECM incorporates a self diagnosis facility.				
When an out of range signal occurs,				
A fault code is logged and recorded in the ECM and the Check Engine Light is illuminated.				
With intermittent faults, the Check Engine Light may extinguish,				
However, the fault code will remain stored in the ECM unless it is erased.				

**DAIHATSU APPLAUSE A101 1.6L (HD-E Engine) 1988-1995 Engine Management System**



Applause / Feroza ECM Connector (Backprobing View)

ECM Voltage table				
Pin#	Circuit	Condition	Status	Voltage
<b>Connector "A"</b>				
A1	Earth		All Times	0 Volts
A2	Injectors		Ignition ON Engine cranking or running	Battery Volts Voltage Pulses
A3	ECM Power Supply		Ignition ON	Battery Volts
A4	Backup Power Supply		All Times	Battery Volts

A5	Idle Up VSV	Ignition ON	Engine @ operating Temperature	Battery Volts	
			Idle Up VSV ON	< 3 Volts	
A6	Oxygen Sensor Test Connector	Engine @ operating temperature	Engine speed held steady @ 3000 RPM approx		
			Switching > 8 times in 10 seconds	0.5 Volts approx.	
A7	Earth		All Times	0 Volts	
A8	Injectors		Ignition ON	Battery Volts	
			Engine cranking or running	Voltage Pulses	
A9	ECM Power Supply		Ignition ON	Battery Volts	
A10	Check Engine Light (CEL)		Ignition ON + CEL pin shortcut	< 3 Volts	
			Engine running CEL OFF	Battery Volts	
A11	Fuel Pump Relay	Ignition ON	Fuel Pump operating	< 1 Volts	
			Fuel Pump NOT operating	Battery Volts	
A12	Earth		All Times	0 Volts	
	Connector "B"				
B1	Ignition Signal		Ignition ON	Battery Volts	
			Engine cranking or running	Voltage Pulses	
B2	Starter Motor Signal		Engine cranking	6.0 to 15.5 Volts	
B3	Diagnostic Connector Test Terminal		Ignition ON	Battery Volts	
B4	Idle Switch	Ignition ON	Throttle closed	1.0 Volts or less	
			Throttle open	Battery Volts	
B5	Electrical Load Signal		Headlamps ON	Battery Volts	
			Demister ON	Battery Volts	
			All Other Times	0 Volts	

B6	MAP sensor Power Supply		Ignition ON	4.5 to 5.5 Volts	
B7	MAP Sensor		Ignition ON, Engine OFF	3.2 to 3.8 Volts	
B8	Intake Air Sensor	Surge Tank Air Temp. @ 20°C	Ignition ON	0.9 to 3.0 Volts	
B9	Engine Coolant Temp. Sensor	Engine Coolant Temp. @ 80-90°C	Ignition ON	0.4 to 0.5 Volts	
B10	MAP Sensor Earth		All Times	0 Volts	
B11	Air Conditioner Clutch		Ignition ON Air Conditioner ON	0 Volts Battery Volts	
B13	Transmission Detection (Applause Only)	Ignition ON	Manual Vehicles. Automatic Vehicles	Battery Volts 0 Volts	
B14	Vehicle Speed Sensor	Ignition ON	Vehicle stationary Front wheels rotating	0 or Battery Volts 0 to Battery Volts fluctuations	
B15	Transmission Shift Position Switch (Applause Automatic Only)	Ignition ON	D, 2,L or R selected P or N selected	1.0 Volts or less Battery Volts	
B16	Throttle Position Sensor Power Switch	Ignition ON	Throttle Closad Trhottle Open	4.5 to 5.5 Volts 1.0 Volts or less	
B17	Oxygen Sensor		Engine @ operating temperature Engine speed held steady @ 2000 RPM approx.	Switching > 8 times in 10 seconds 0 and 1 Volts	
B18	Sensor Ground		Ignition ON	0 Volts	